# 501-7: Frame not working

| PICTURE: | PROBLEM: | SOLUTION: |
|---|---|---|
|  | Is there a red light in the transformer? | 1. Check 220V outlet and wire to transformer. <br> 2. Unplug for 3 minutes, plug in again. <br> 3. Still no light = **Change the transformer Item no. R323670** |

**NO** →

**YES** ↓

|  | Connect the motor to the transformer - very briefly. (Remove quickly!) **Was the frame moving?** | **Change the column Item no. 501-7 7S (silver) or 501-7 7B (black)** |

**NO** →

**YES** ↓

|  | Connect the wires again (red/red), according to the assembly instructions. <u>Click here for assembly instruction</u> | |

↓

|  | Check if the buttons are used correctly. <u>Click here for mounting instructions</u> **Does the frame work?** | **Change the control panel Item no. R105020** |

**NO** →

**YES** ↓

| | **Congratulations!** Your height adjustable frame is now working. | |